



Tablet Security Lock Stand


Cavo di Sicurezza con Supporto Universale
per Tablet PC 8"-13"

Contenuto della Confezione				
Supporto 	Cavo 	2 Chiavi 	4 Viti (4.2 x 25 mm) 	Manuale 

Installare il Tablet




1. Tenere premuto il pulsante di rilascio per sbloccare il frame.




2. Regolare il frame per il proprio Tablet.

Angolo Regolabile


360°




160°



Bloccare il Frame Antifurto




1. Avvolgere il cavo attorno ad un oggetto inamovibile.




2. Inserire il cavo nello slot di sicurezza del frame.
3. Premere il pulsante di blocco per assicurare frame e cavo.

Sbloccare il Frame Antifurto




1. Inserire la chiave nel pulsante di blocco per sbloccare il cavo.



2. Estrarre il cavo e la chiave per sbloccare il frame antifurto.


Fissare la base




Usare le viti in dotazione per fissare la base del supporto a una superficie in legno.

Tablet Security Lock Stand


Security Lock Cable with Universal Stand for 8"-13" Tablet PC

Package Contents				
Stand 	Cable 	2 Keys 	4 Screws (4.2 x 25 mm) 	Manual 


Install the Tablet PC




1. Press and hold on the release button to unlock the frame.




2. Adjust the frame to fit your Tablet PC.



Lock the Security Frame




1. Loop the cable around a secure object.




2. Insert the cable into the security slot.

3. Press the lock button to lock the frame and cable.

Unlock the Security Frame




1. Insert the key into the lock button to release the cable.



2. Take out cable and key to unlock.

Fix the base



Use the screws included to fix the stand on wooden surface.