

Hamlet

USB 3.0 MIRROR DISK Box Esterno per Hard Disk SATA da 2.5"



MANUALE UTENTE

HXD25U3Mxx
Rev. 3.0

www.hamletcom.com

Gentile Cliente,

La ringraziamo per la fiducia riposta nei nostri prodotti. La preghiamo di seguire le norme d'uso e manutenzione che seguono. Al termine del funzionamento di questo prodotto La preghiamo di non smaltirlo tra i rifiuti urbani misti, ma di effettuare per detti rifiuti una raccolta separata negli appositi raccoglitori di materiale elettrico/elettronico o di riportare il prodotto dal rivenditore che lo ritirerà gratuitamente.

Informiamo che il prodotto è stato realizzato con materiali e componenti in conformità a quanto previsto dalla Direttiva RoHS 2011/65/EU & 2015/863/EU, dalla Direttiva RAEE 2002/96/CE e 2003/108/CE D.Lgs. 151/2005 e dalla Direttiva EMC 2014/30/EU per i seguenti standard: EN 55022: 2010, EN 61000-3-2: 2014, EN 61000-3-3: 2013, EN 55024: 2010, EN 61000-4-2: 2009.



La dichiarazione di conformità CE completa relativa al prodotto può essere richiesta contattando Hamlet all'indirizzo e-mail info@hamletcom.com.

Visita www.hamletcom.com per informazioni complete su tutti i prodotti Hamlet e per accedere a download e supporto tecnico.

Importato da: CARECA ITALIA SPA - Scandiano (RE) . Italia.

Marchi e variazioni

Tutti i marchi e i nomi di società citati in questa guida sono utilizzati al solo scopo descrittivo e appartengono ai rispettivi proprietari. La presente guida ha scopo puramente informativo e può essere modificata senza preavviso.

Informazioni importanti

Hamlet non garantisce in nessuna circostanza il recupero o il ripristino dei dati in caso di danni o perdita riconducibili all'uso dell'unità. Per prevenire possibili perdite di dati, si consiglia vivamente di effettuare DUE copie dei dati e di conservarne ad esempio una su un'unità disco esterna e l'altra sull'unità disco interna, oppure su un'altra unità disco esterna o su un supporto di archiviazione rimovibile.

Introduzione

Requisiti di sistema

- Windows XP/Vista/7/8 e 10, Mac OS 10.4 o superiore, Linux (kernel 2.6.31 o sup.)
- Porta USB 3.0 per prestazioni USB 3.0

Contenuto della confezione

- Box esterno USB 3.0
- Utility CD
- Cavo USB 3.0
- Manuale utente

Installazione del disco fisso

1. Svitare le 4 viti di fissaggio per rimuovere il pannello superiore.
2. Collegare il disco fisso al connettore SATA presente sulla scheda.
3. Riposizionare la parte superiore del box e fissarla con le viti.
4. L'installazione dell'hardware è completa. Il disco è ora pronto per essere collegato al computer.

Installazione dell'unità

1. Collegare il cavo USB 3.0 al computer e all'unità.
2. L'unità verrà riconosciuta automaticamente dal sistema e la relativa icona verrà visualizzata in "Risorse del computer" (Windows) o sulla "Scrivania" (Mac).

ATTENZIONE: Prima di iniziare ad utilizzare l'unità è necessario procedere alla formattazione. Si prega di fare riferimento al manuale del proprio sistema operativo per la corretta procedura di formattazione.

Uso della funzione OTB (One-Touch-Backup)

La funzione One-Touch-Backup (OTB) permette di eseguire il backup dei dati sul disco esterno tramite la pressione di un solo pulsante posto sul dispositivo. Il pulsante OTB deve essere configurato con il software allegato al prodotto (solo per Windows).

Scollegare dispositivi USB

Se il dispositivo è dotato di una spia di attività, prima di scollegarlo attendere qualche secondo dopo che la spia ha smesso di lampeggiare.

Utenti Windows

Se viene visualizzata l'icona "Rimozione sicura dell'hardware" nell'area di notifica nella parte destra della barra delle applicazioni, è possibile utilizzarla per rimuovere il dispositivo.

1. Fare clic sull'icona "Rimozione sicura dell'hardware".
2. Fare clic sull'unità che si desidera scollegare.
3. Viene visualizzato il messaggio: "Rimozione sicura dell'hardware" o un altro messaggio equivalente. A questo punto la periferica può essere rimossa senza alcun problema.

Utenti Mac

Per espellere un disco o un volume, eseguire una di queste operazioni:

- Selezionare l'icona dell'elemento da espellere e scegliere Archivio > Espelli.
- Trascinare l'icona dell'elemento sull'icona del Cestino nel Dock (durante il trascinamento l'icona del Cestino si trasforma in icona di espulsione).

MAN.rev.2020-05

Hamlet

USB 3.0 MIRROR DISK Enclosure for 2.5" SATA Hard Disk



USER MANUAL

HXD25U3Mxx
Rev. 3.0

www.hamletcom.com

Dear Customer,
thanks for choosing an Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.

We inform You this product is manufactured with materials and components in compliance with RoHS Directives 2011/65/EU & 2015/863/EU, WEEE Directive 2002/96/EC and 2003/108/EC Italian Legislative Decree 2005/151 and EMC Directive 2014/30/EU for the following standards: EN 55022: 2010, EN 61000-3-2: 2014, EN 61000-3-3: 2013, EN 55024: 2010, EN 61000-4-2: 2009.



The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at info@hamletcom.com.
Visit www.hamletcom.com for complete information on all Hamlet products and to access downloads and technical support.
Imported by: CARECA ITALIA SPA - Scandiano (RE) . Italy.

Trademarks and changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners. The material in this document is for information only and subject to change without notice.

Important information

Any loss, corruption or destruction of data while using a Hamlet drive is the sole responsibility of the user, and under no circumstances will Hamlet be held liable for the recovery or restoration of this data. To help prevent the loss of your data, it is highly recommended that you keep TWO copies of your data; one copy on your external hard drive, for instance, and a second copy either on your internal hard drive, another external hard drive or some other form of removable storage media.

Introduction

System Requirements

- Windows XP/Vista/7/8/10, Mac OS 10.4 or above, Linux (kernel 2.6.31 or above)
- Available USB 3.0 port for USB 3.0 speed

Package content

- External USB 3.0 Enclosure
- USB 3.0 Cable
- Utility CD
- User's manual

Hard Disk installation

1. Unscrew the 4 screws to remove the top cover of the enclosure.
2. Connect the 2.5" SATA hard drive carefully to the SATA connector of the enclosure.
3. Put the top cover back to the case and fix it with the screws.
4. The hardware installation is complete. The enclosure is now ready to use.

Device installation

1. Connect the USB 3.0 cable to your computer and to the drive.
2. The drive will mount in My Computer (Windows) or on your Desktop (Mac).

IMPORTANT NOTE: Before using your external storage device, the hard drive must be formatted. Please refer to your Operating System manual for the correct formatting procedure.

Using the OTB (One-Touch-Backup) function

The One-Touch-Backup (OTB) function allows you to back up data on external hard drive by pressing a single button on the device. OTB button must be configured with the software supplied with the product (Windows only).

Connecting and disconnecting USB devices

Most USB devices can be removed and unplugged at will. When unplugging storage devices, such as USB flash drives, you should be sure that the computer has finished saving any information to the device before removing it. If the device has an activity light, wait for a few seconds after the light has finished flashing before unplugging it.

Windows Users

If you see the "Safely Remove Hardware" icon in the notification area at the far right of the taskbar, you can use this to ensure that devices have finished all operations in progress and are ready to remove.

1. Click the "Safely Remove Hardware" icon.
2. You'll see a list of connected devices.
3. Click the device you want to remove.

Mac Users

To eject a disk or volume, do one of the following:

- Select the item to eject, and choose File > Eject.
- Drag the item to the Trash icon in the Dock (While you drag, the Trash icon changes to an Eject icon).

MAN.rev.2020-05