

Hamlet

4 PORT USB 2.0 480 Mbps High Speed Hub



Manuale Utente XHUB4020AL

www.hamletcom.com

Gentile Cliente,

La ringraziamo per la fiducia riposta nei nostri prodotti. La preghiamo di seguire le norme d'uso e manutenzione che seguono. Al termine del funzionamento di questo prodotto La preghiamo di non smaltirlo tra i rifiuti urbani misti, ma di effettuare per detti rifiuti una raccolta separata negli appositi raccoglitori di materiale elettrico ed elettronico o di riportare il prodotto dal rivenditore che lo ritirerà gratuitamente.

Informiamo che il prodotto è stato realizzato con materiali e componenti in conformità a quanto previsto dalle Direttive RoHS 2011/65/EU, RAEE 2002/96/CE, 2003/108/CE D.lgs. 151/2005 e dalla Direttiva EMC 2014/30/EU per i seguenti standard:

EN 55022: 2010
EN 61000-3-2: 2014
EN 61000-3-3: 2013
EN 55024: 2010



La dichiarazione di conformità CE completa relativa al prodotto può essere richiesta contattando Hamlet all'indirizzo e-mail info@hamletcom.com. Visita www.hamletcom.com per informazioni complete su tutti i prodotti Hamlet e per accedere a download e supporto tecnico.

Importato da: CARECA ITALIA SPA - Scandiano (RE) - Italia.

Marchi e variazioni

Tutti i marchi e i nomi di società citati in questa guida sono utilizzati al solo scopo descrittivo e appartengono ai rispettivi proprietari.

La presente guida ha scopo puramente informativo. I contenuti, le specifiche e le caratteristiche esteriori del prodotto sono indicative e possono variare senza obbligo di preavviso.

Descrizione

Hamlet 4 Port USB 2.0 è un Hub esterno consente di replicare la porta USB 2.0 del vostro computer per collegare fino a 4 dispositivi. La connessione USB 2.0 offre eccellenti prestazioni ed è compatibile con tutti i computer dotati di porta USB.

Requisiti di sistema

- Computer con porta USB 2.0
- Windows XP/Vista/7/8 e 10, Mac OS X 10.4 o superiore, Linux

Contenuto della confezione

- Hub USB 2.0
- Manuale utente

Installazione ed Utilizzo del prodotto

1. Collegare il connettore USB ad una porta USB del computer.
2. Connettere i dispositivi USB alle porte USB 2.0 dell'Hub.
3. I dispositivi collegati verranno riconosciuti dal sistema e la relativa icona apparirà in "Risorse del computer" (Windows) o sulla "Scrivania" (Mac).

Scollegare dispositivi USB

Se il dispositivo è dotato di una spia di attività, prima di scollegarlo attendere qualche secondo dopo che la spia ha smesso di lampeggiare.

Utenti Windows

Se viene visualizzata l'icona "Rimozione sicura dell'hardware" nell'area di notifica nella parte destra della barra delle applicazioni, è possibile utilizzarla per rimuovere il dispositivo.

1. Fare clic sull'icona "Rimozione sicura dell'hardware".
2. Fare clic sull'unità che si desidera scollegare.
3. Viene visualizzato il messaggio: "Rimozione sicura dell'hardware" o un altro messaggio equivalente. A questo punto la periferica può essere rimossa senza alcun problema.

Utenti Mac

Per espellere un disco o un volume, eseguire una di queste operazioni:

- Selezionare l'icona dell'elemento da espellere e scegliere Archivio > Espelli.
- Trascinare l'icona dell'elemento sull'icona del Cestino nel Dock (l'icona del Cestino si trasforma in icona di espulsione).

Hamlet

4 PORT USB 2.0 480 Mbps High Speed Hub



User Manual XHUB4020AL

www.hamletcom.com

Dear Customer,
Thanks for choosing a Hamlet product. Please carefully follow the instructions for its use and maintenance and, once this item has run its life span, we kindly ask You to dispose of it in an environmentally friendly way, by putting it in the separate bins for electrical/electronic waste, or to bring it back to your retailer who will collect it for free.

We inform You this product is manufactured with materials and components in compliance with RoHS Directive 2011/65/EU, with WEEE Directive 2002/96/CE, 2003/108/CE Italian Legislative Decree 2005/151 and EMC Directive 2014/30/EU for the following standards:

EN 55022: 2010
EN 61000-3-2: 2014
EN 61000-3-3: 2013
EN 55024: 2010



The complete CE declaration of conformity of the product can be obtained by contacting Hamlet at info@hamletcom.com.
Visit www.hamletcom.com for complete information on all Hamlet products and to access downloads and technical support.

Imported by: CARECA ITALIA SPA - Scandiano (RE) . Italy.

Trademarks and changes

All trademarks and company names mentioned in this manual are used for description purpose only and remain property of their respective owners.
The material in this document is for information only. Contents, specifications and appearance of the product are indicative and may change without notice.

Description

Hamlet 4 Port USB 2.0 is an external USB 2.0 Hub which allows you to replicate the USB 2.0 port of your computer to connect up to 4 devices. The USB 2.0 connection provides excellent performance and is compatible with all computers with a USB port.

System Requirements

- Computer with an available USB 2.0 port
- Windows XP/Vista/7/8 and 10, Mac OS X 10.4 or later, Linux

Package content

- USB 2.0 Hub
- User manual

Installation and use

1. Connect the USB connector to a USB port of your computer.
2. Plug in your USB devices to the Hub's USB 2.0 ports.
3. The devices will mount in "My Computer" (Windows) or on your "Desktop" (Mac).

Connecting and disconnecting USB devices

Most USB devices can be removed and unplugged at will. When unplugging storage devices, such as USB flash drives, you should be sure that the computer has finished saving any information to the device before removing it. If the device has an activity light, wait for a few seconds after the light has finished flashing before unplugging it.

Windows Users

If you see the "Safely Remove Hardware" icon in the notification area at the far right of the taskbar, you can use this to ensure that devices have finished all operations in progress and are ready to remove.

1. Click the "Safely Remove Hardware" icon.
2. You'll see a list of connected devices.
3. Click the device you want to remove.

Mac Users

To eject a disk or volume, do one of the following:

- Select the item to eject, and choose File > Eject.
- Drag the item to the Trash icon in the Dock (While you drag, the Trash icon changes to an Eject icon).